

# CPU-HOLDER, WALL MOUNTED



## ADRESS

Hårup Skovvej 2  
8600 Silkeborg  
Danmark

## CONTACT

+ 45 86 81 23 75  
info@pj-production.dk

## WEBSITES

[www.pj-production.dk/eng](http://www.pj-production.dk/eng)  
[www.aptocollection.dk/eng](http://www.aptocollection.dk/eng)



# CPU-HOLDER


WALL MOUNTED

---

Why only use the installation opportunity underneath the desktop, when the working environment has numerous other surfaces recommendable for installation. This CPU-holder must be mounted directly on the wall, which, besides space optimization, gives the employees full access to the working station without any disturbing factors.

## CHARACTERISTCA:


- The CPU-holder has width adjustment om 45 mm. - 160 mm., which makes it possible to use this CPU-holder for a broad array of computers unaffected by the size.
- The wall-mounted CPU-holder can carry up to 20 kg




## CPU-HOLDER - WALL MOUNTED

1560-9005 // 1590-9006 / 1560-9016

**Height:** 200 mm.  
**Wicth:** 250 mm.  
**Debth:** 45-180 mm.



250



200



140

Min: 45  
Max: 180